

# Hardware Reference Manual

REV. March 2019

---

## **Swordtail (VL-EPC-2702)**

Arm\* i.MX6 Single Board Computer  
with Gigabit Ethernet, Video, USB,  
Bluetooth, Wi-Fi, Cellular, Digital  
I/O, CAN Bus and I<sup>2</sup>C





[WWW.VERSALOGIC.COM](http://WWW.VERSALOGIC.COM)

12100 SW Tualatin Road  
Tualatin, OR 97062-7341  
(503) 747-2261  
Fax (971) 224-4708

Copyright © 2019 VersaLogic Corp. All rights reserved.

**Notice:**

Although every effort has been made to ensure this document is error-free, VersaLogic makes no representations or warranties with respect to this product and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose.

VersaLogic reserves the right to revise this product and associated documentation at any time without obligation to notify anyone of such changes.

\* Other names and brands may be claimed as the property of others.

## Product Release Notes

- Rev 1.00** Initial draft
- Rev 1.01** Updated cable information for J13 in table 2

## Support Page

The [Swordtail Support Page](#) contains additional information and resources for this product including:

- Operating system information and software drivers
- Data sheets and manufacturers' links for chips used in this product
- U-Boot information and upgrades

## VersaTech KnowledgeBase

The VersaTech KnowledgeBase contains useful technical information about VersaLogic products, along with product advisories.

## Customer Support

If you are unable to solve a problem after reading this manual, visiting the product support page, or searching the KnowledgeBase, contact VersaLogic Technical Support at (503) 747-2261. VersaLogic support engineers are also available via e-mail at [Support@VersaLogic.com](mailto:Support@VersaLogic.com).

## Repair Service

If your product requires service, you must obtain a Returned Material Authorization (RMA) number by calling (503) 747-2261. Be ready to provide the following information:

- Your name, the name of your company, your phone number, and e-mail address
- The name of a technician or engineer that can be contacted if any questions arise
- The quantity of items being returned
- The model and serial number (barcode) of each item
- A detailed description of the problem
- Steps you have taken to resolve or recreate the problem
- The return shipping address

**Warranty Repair:** All parts and labor charges are covered, including return shipping charges for UPS Ground delivery to United States addresses. For international address the customer is fully responsible for shipping (including taxes and duties) to and from the factory.

**Non-warranty Repair:** All approved non-warranty repairs are subject to diagnosis and labor charges, parts charges and return shipping fees. Specify the shipping method you prefer and provide a purchase order number for invoicing the repair.

**Note:** Mark the RMA number clearly on the outside of the box before returning.

# Contents

---

<b>Introduction .....</b>	<b>6</b>
Description.....	6
Features and Construction .....	6
Technical Specifications.....	7
Thermal Considerations.....	7
Block Diagram.....	8
Cautions .....	9
Electrostatic Discharge .....	9
Handling Care .....	9
Earth Ground Requirement.....	9
<b>Configuration and Setup.....</b>	<b>10</b>
Initial Configuration .....	10
Basic Setup .....	10
Physical Layout .....	11
Swordtail Dimensions.....	11
Hardware Assembly.....	11
External Connectors .....	12
<b>System Features.....</b>	<b>15</b>
Power Supply.....	15
Power Connectors.....	15
CPU.....	15
System RAM.....	15
<b>Interfaces and Connectors .....</b>	<b>16</b>
Headers and Jumpers .....	16
V1 – BOOT_MODE0/USG_OTG_ID Jumper.....	16
V2 - CAN1 Termination Jumper .....	16
Storage Interfaces .....	17
MicroSD Interface (J4).....	17
Network Interface .....	17
Ethernet Interface (J5) .....	17
Video Interfaces.....	18
HDMI (J6) .....	18
LVDS (J7).....	18
LVDS Backlight (J8).....	19
Touchscreen(J21) .....	19

I/O Interfaces .....	20
USB Interfaces (J1) .....	20
User I/O (J13) .....	20
CAN Interface (J17) .....	21
COM1 Interface (J16).....	21
Cellular Socket (J20A and J20B together form 20-pin socket).....	21
Push Buttons .....	24
<b>Appendix A – References.....</b>	<b>25</b>

---

## Figures

Figure 1. Swordtail Board Block Diagram .....	8
Figure 2. Swordtail Board Dimensions and Mounting Holes .....	11
Figure 3. Connector Locations .....	12

---

## Tables

Table 1. Environmental Specifications.....	7
Table 2. Connector Functions and Interface Cables .....	13
Table 3. Jumper Information .....	14
Table 4. J15 Main Power Connector Pinout.....	15
Table 5. Power Requirements.....	15
Table 6. V1 Pinout .....	16
Table 7. V2 Pinout .....	16
Table 8. J4 MicroSD Pinout .....	17
Table 9. J5 Ethernet RJ45 Pinout .....	17
Table 10. HDMI Connector Pinout .....	18
Table 11. LVDS Connector Pinout .....	18
Table 12. LVDS Backlight Connector Pinout .....	19
Table 13. Touchscreen Pinout .....	19
Table 14. USBx2 2.0 Connector Pinout .....	20
Table 15. User I/O Pinouts .....	20
Table 16. CAN Pinouts .....	21
Table 17. COM1 Pinout .....	21
Table 18. Cellular Socket Pinout.....	21
Table 19. Push Buttons and Designators .....	24

## Description

### Features and Construction

The Swordtail single-board computer is a complete Wi-Fi and Bluetooth\* enabled, Arm\*-based embedded computer. Models are available with power-efficient, dual-core or quad-core i.MX6 CPUs. These boards are designed for applications that demand rugged, power-efficient solutions such as industrial machine automation, transportation, medical, kiosk, and industrial IoT applications. Swordtail boards have been designed to enable transactions and transmission of maintenance or diagnostic information without the presence of a wired data connection. Both Wi-Fi and Bluetooth\* radios are included on board, and a NimbleLink Skywire\* socket supports a wide range of optional cellular and other wireless plug-ins.

Swordtail is a complete board-level computer. Additional carrier boards, connector boards, or I/O expansion boards are not required for operation. Swordtail boards are delivered with on-board soldered-down RAM, ready to plug-in and run. To simplify mounting and future upgrades, the Swordtail leverages the COM-Express standard for its footprint and mounting points.

- Arm\* i.MX6 dual or quad-core processors
- 95 x 95 mm size
- Low power draw
- Fanless operation
- Up to 4 GB soldered-on RAM
- Gigabit Ethernet
- HDMI video
- LVDS video
- CAN Bus
- Cellular support
- Bluetooth\*
- Wi-Fi
- USB 2.0 ports
- MicroSD card socket
- RS-232
- I<sup>2</sup>C with interrupt input support
- Optional eMMC Flash. Up to 32 GB
- Linux support

VL-EPC-2702 boards receive complete functional testing and are backed by a limited five-year warranty. Careful parts sourcing and US-based technical support ensure the highest possible quality, reliability, service, and product longevity for this exceptional single-board computer (SBC).

## Technical Specifications

See the [Swordtail Data Sheet](#) for complete specifications.

## Thermal Considerations

The operating temperature for the Swordtail is -40°C to +85°C, de-rated -1.1°C per 305m (1,000 ft.) above 2,300m (7,500 ft.).


**Table 1. Environmental Specifications**

Characteristic	Value
Operating Temperature	Ext Temp (-40°C to +85°C)
Storage Temperature	-40°C to +85°C
Cooling	Fanless. Heatsink for SoC
Airflow Requirements	100 Linear Feet per Minute
Thermal Shock	5°C/min. over operating temperature
Humidity	Less than 95%, noncondensing
Vibration, Sinusoidal Sweep	MIL-STD-202H Sinusoidal sweep: Method 204, Modified Condition A, 2g constant acceleration from 5 to 500 Hz, 20 minutes per axis
Vibration, Random	Random vibration: Method 214A, Condition A, 5.35g rms, 5 minutes per axis
Mechanical Shock	Shock: Method 213B, Condition G, 20g half-sine, 11 msec duration per axis

**Note:** Cellular modules may become unseated during vibrations and mechanical shock. Evaluate for each usage case.

# Block Diagram

Figure 1. Swordtail Board Block Diagram





## Cautions

### Electrostatic Discharge



**CAUTION:**

Electrostatic discharge (ESD) can damage circuit boards, disk drives, and other components. Handle circuit board at an ESD workstation. If an approved station is not available, wearing a grounded antistatic wrist strap provides some measure of protection. Keep all plastic away from the board, and do not slide the board over any surface.

After removing the board from its protective wrapper, place the board on a grounded, static-free surface, component side up. Use an antistatic foam pad if available.

Ship and store the board inside a closed metallic antistatic envelope for protection.

**Note:** The exterior coating on some metallic antistatic bags is sufficiently conductive to cause excessive battery drain if the bag comes in contact with the bottom side of the Swordtail.

### Handling Care



**CAUTION:**

Avoid touching the exposed circuitry with your fingers when handling the board. Though it will not damage the circuitry, it is possible that small amounts of oil or perspiration on the skin could have enough conductivity to cause the contents of CMOS RAM to become corrupted through careless handling, resulting in CMOS resetting to factory defaults.

### Earth Ground Requirement



**CAUTION:**

All mounting standoffs for EPC boards should be connected to earth ground (chassis ground). This provides proper grounding for EMI purposes.

# Configuration and Setup

# 2

## Initial Configuration

Use the following components for a typical development system:

- Swordtail (VL-EPC-2702) computer
- VL-PS-WALL12-24 wall mount 12V 24W power supply
- VL-F41-8SBN-LINUX3 – 8GB MicroSD card with bootable Linux, standard temp
- USB keyboard and mouse
- HDMI monitor and cable

**Note:** VL-CKR-Swordtail includes VL-F41-8SBN-LINUX3, CBR-0205, CBR-ANT04, CBR-0504, CBR-3004 and PS-WALL12-24.

## Basic Setup

### 1. Attach Cables and Peripherals

- Attach a HDMI display to the HDMI connector at J6. Plug in a USB keyboard, and a USB mouse into the USB connectors at J1 (Note if using the top USB port, you must install the jumper on V1 pins 3-4 for the OTG USB port to be placed in Host mode. Alternatively, you can use an external USB Hub to provide separate mouse and keyboard connections for the bottom USB port. Make sure the upstream USB Hub port (connecting to the EPC-2702 host port) does not provide VBUS power, but the downstream USB Hub port(s) can be externally powered to ease the loading on the EPC-2702 power supply.)
- Insert a VL-F41-8SBN-LINUX3 MicroSD card into the MicroSD slot located at J4

### 2. Review Configuration

- Before you power up the system, double-check all the connections. Make sure all cables are oriented correctly and that there is adequate power to the VL-EPC-2702 and peripheral devices.

### 3. Power On

- Turn on the video monitor, and then plug the power adapter cable VL-PS-WALL12-24 into the power jack J15. The presence of a video signal indicates proper configuration of the system.

**Note:** Booting and operating the Yocto Linux operating system is covered in the VersaLogic Yocto Linux User Guide.


## Physical Layout

### Swordtail Dimensions

The figure below shows board dimensions to help with pre-production planning and layout.

**Figure 2. Swordtail Board Dimensions and Mounting Holes**

*(Not to scale. All dimensions in millimeters.)*




### Hardware Assembly

The entire assembly can fit on a tabletop. When bolting the unit down, make sure to secure all standoffs to the mounting surface to prevent circuit board flexing. Standoffs secure the top circuit board using four pan head screws.

## External Connectors

Figure 3. Connector Locations



### Swordtail Connector Functions and Interface Cables

The table below provides information about the function, mating connectors, and transition cables for Swordtail connectors.

**Table 2. Connector Functions and Interface Cables**

Connector	Function	Mating Connector/Device	Transition Cable	Cable/Device Description
J1	USB (dual stacked)	Standard USB Type A	—	Male Type A USB 2.0 to Male Type B for downstream devices, Male Type A USB 2.0 to Male Type A USB 2.0 for top port only when OTG port is set as Device mode (V1 jumper off).
J4	MicroSD	8GB microSD card with bootable Linux 2GB microSD card 4GB microSD card 8GB microSD card	—	VL-F41-8SBN-LINUX3 (MLC, Standard Temperature) VL-F41-2EBN (SLC, Extended Temperature) VL-F41-4EBN (SLC, Extended Temperature) VL-F41-8EBN (SLC, Extended Temperature)
J5	Ethernet	RJ45 Crimp-on Plug		Cat5e Ethernet Patch Cable
J6	HDMI	Standard HDMI	—	—
J7	LVDS Panel	Hirose DF19G-20P-1H(54)	VL-CBR-2015 VL-CBR-2016 VL-CBR-2017	20-pin Hirose 1mm to Hirose 1mm 24-bit cable 20-pin Hirose 1mm to JAE 1.25mm 18-bit cable 20-pin Hirose 1mm to 20-pin Hirose 1.25mm 24-bit cable
J8	Backlight	Molex 5013300400	VL-CBR-0404	20" 12V LED Backlight Control Cable
J13	User I/O	0.5m 30-pin 2mm IDC to Ribbon Cable	—	VL-CBR-3004
J15	Power	DC Power Jack, 2.0mm positive center pin	—	VL-PS-WALL12-24
J16	COM1	—	VL-CBR-0504	(Micro-Latch to DB9)
J17	CAN1	—	VL-CBR-0405 VL-CBR-0406	(Micro-Latch to Micro-Latch) (Micro-Latch to DB9 )
J20A/J20B	Cellular Socket	20-pin NimbleLink Skywire socket	—	—
J21	Touchscreen	—	—	VL-CBR-0811

Table 3. Jumper Information

EPC-2702 Reference Designator	EPC-2702 Signal Name	Control/Description
V1	Pins 1-2 - BOOT_MODE0 Pin 3-4 - USB_OTG_ID	<p>With jumper installed on pins 1-2, BOOT_MODE0 = 1, to allow use of USB OTG Device communications using the NXP i.MX6 Serial Downloader method. When this jumper is installed V1 pins 3-4 should not have a jumper installed.</p> <p>With the jumper installed on pins 3-4, the USB OTG port behaves as a Host Port and will enable the power switch to the Type A connector (top socket of J1), ensure that the cable connection goes to a Device and not another Host.</p>
V2	Pins 1-2 - CAN1_SPLIT / CAN1_R_P Pins 3-4 - CAN1_SPLIT / CAN1_R_N	<p>Default: Jumper on pins 1-2 and jumper on pins 3-4 sets 120 Ohm termination for end node and split termination capacitor connections between CAN1_P/N.</p> <p>Remove both jumpers to disconnect all termination.</p> <p>Place one jumper across pins 2-4 to bypass capacitor to have 120 Ohms resistor termination only.</p>

## Power Supply

### Power Connectors

Main power is applied to the Swordtail through a center-pin connector (J15) (there are two pin 1's), with mating connector VersaLogic VL-PS-WALL12-24. See the table below for connector pinout.



#### CAUTION:

To prevent severe and possibly irreparable damage to the system, it is critical that the power connectors are wired correctly. The power connector is not fuse or diode protected. Proper polarity must be followed otherwise damage will occur.

There is an alternate method to provide power the power input via J13. Please see the I/O Interfaces User I/O pin out information. Choose one power input method, as there is no reason to use of both.

**Table 4. J15 Main Power Connector Pinout**

Pin	Signal	Description
1	V_MAIN (first pin)	Center Pin Voltage
1	V_MAIN (second pin)	Center Pin Voltage
2	Ground	Ground Sleeve
3	Plug Detection	Grounded when no plug, open otherwise.

**Note:** The power measurements reflect the Ethernet (eth0) down and Wi-Fi (wlan0) producing the connected values while running a benchmark test in Linux called Himeno with 4 threads. The test was run at room temperature.

**Table 5. Power Requirements**

Model	Idle	Typical	Max.
VL-EPC-2702-EBK-01	1.74W	2.25W	2.75W
VL-EPC-2702-EDK-02	2.03W	2.97W	3.9W

## CPU

The Swordtail uses a low power Arm i.MX 6 DualLite or Quad-core processor.

- NXP i.MX 6Dual/**6Quad** Arm processors - [Specification](#)
- NXP i.MX 6Solo/**6DualLite** Arm processors – [Specification](#)

## System RAM

The Swordtail ships with 1 GB with the DualLite or 2 GB with the Quad of soldered-on DDR3L RAM. Both processors support customization of the memory capacity to 4 GB.

# Interfaces and Connectors

# 4

## Headers and Jumpers

### V1 - BOOT\_MODE0/USB\_OTG\_ID Jumper

The EPC-2702 uses a 4-pin jumper to provide access to two required boot modes as well as providing a control setting for the USB OTG block to function as either an OTG port set to device mode or set to host mode.

The jumper ships in a storage position, with the boot mode defaulting to boot from the eFuses and the USB OTG port set to Device mode (top USB port on J1). Putting the jumper on pins 1-2 allows the board to run in Serial Download mode waiting to boot from a USB Host connection (local USB set to device mode by default). Putting the jumper on pins 3-4 sets the USB OTG port to Host mode, allowing the user to connect a downstream device. Never use more than one jumper on this header as there is no case where that would be useful.

**Note:** For custom product designs, there are placeholders to bypass and hard strap the jumper settings.

**Table 6. V1 Pinout**

Pin	Signal Name
1	PU_BOOT_MODE0
2	BOOT_MODE0
3	USB_OTG_ID
4	GND

### V2 - CAN1 Termination Jumper

The EPC-2702 uses two jumpers to provide two 60 Ohm bus termination resistors. There is a split termination capacitor to GND between them for the CAN1 bus termination solution when a jumper is installed each on pins 1-2 and pins 3-4. The split termination capacitor can be removed from the path by removing these two jumpers and placing one of them on pins 2-4 to provide only the 120 Ohm bus termination.

If no termination enabled is preferred (when the bus is mid-point on a CAN bus network), both jumpers can be removed to open the termination path for the bus signals.

**Note:** For custom product designs, there are placeholders to bypass the jumper and still provide any combination of terminations.

**Table 7. V2 Pinout**

Pin	Signal Name
1	CAN1_SPLIT (tied to pin 3)
2	CAN1_R_P (CAN1_P)
3	CAN1_SPLIT (tied to pin 1)
4	CAN1_R_N (CAN1_N)



## Storage Interfaces

Up to 32GB of eMMC Flash storage is available with customization.

### MicroSD Interface (J4)

The table below lists the pinout of the 8-pin MicroSD connector.

Supported VersaLogic SLC extended temperature cards:

- VL-F41-2EBN (2 GB)
- VL-F41-4EBN (4 GB)
- VL-F41-8EBN (8 GB)

**Note:** MicroSD card number VL-F41-8SBN-LINUX3 is an 8 GB MLC MicroSD card with bootable Linux, standard temperature

**Table 8. J4 MicroSD Pinout**

Pin	Signal
1	DAT2
2	CD/DAT3
3	CMD
4	VDD (+3.3V)
5	CLK
6	VSS (GND)
7	DAT0
8	DAT1

## Network Interface

### Ethernet Interface (J5)

The table below lists the pinout of the Ethernet connector.

**Table 9. J5 Ethernet RJ45 Pinout**

J5 RJ45 Pin #	Wire-Color (CAT5E)	10/100 Signals	10/100/1000 Signals
1	White/Orange	+ Auto Switch (can be either Tx or Rx)	BI_DA+
2	Orange	- Auto Switch (can be either Tx or Rx)	BI_DA-
3	White/Green	+ Auto Switch (can be either Tx or Rx)	BI_DB+
4	Blue	+ Auto Switch (can be either Tx or Rx)	BI_DC+
5	White/Blue	- Auto Switch (can be either Tx or Rx)	BI_DC-
6	Green	- Auto Switch (can be either Tx or Rx)	BI_DB-
7	White/Brown	+ Auto Switch (can be either Tx or Rx)	BI_DD+
8	Brown	- Auto Switch (can be either Tx or Rx)	BI_DD-

## Video Interfaces

### HDMI (J6)

Table 10. HDMI Connector Pinout

Pin	Signal	Direction	Description
1	HDMI_D2_P	Out	HDMI Data 2 Differential Pair +
2	DATA2SHIELD	--	Ground
3	HDMI_D2_N	Out	HDMI Data 2 Differential Pair -
4	HDMI_D1_P	Out	HDMI Data 1 Differential Pair +
5	DATA1SHIELD	--	Ground
6	HDMI_D1_N	Out	HDMI Data 1 Differential Pair -
7	HDMI_D0_P	Out	HDMI Data 0 Differential Pair +
8	DATA0SHIELD	--	Ground
9	HDMI_D0_N	Out	HDMI Data 0 Differential Pair -
10	CLK_HDMI_P	Out	HDMI Clock Differential Pair +
11	CLKSHIELD	--	Ground
12	CLK_HDMI_N	Out	HDMI Clock Differential Pair -
13	HDMI_CEC_CON	I/O	HDMI CEC Line
14	HDMI_NC_CON	N/A	No Connect - Resistor to GND option
15	HDMI_SCL_CON_R	Out	DDC Serial Clock Line (5V signal)
16	HDMI_SDA_CON_R	I/O	DDC Serial Data Line (5V signal)
17	HDMI_CEC_GND	I/O	CEC_GND - 0 Ohm Resistor to GND
18	V5_HDMI_CON	Out	5V HDMI Cable Power
19	HDMI_HPD_CON	In	HDMI Hot Plug Detection Signal

### LVDS (J7)

Table 11. LVDS Connector Pinout

Pin	Signal	Description
1	GND	Signal Ground
2	GND	Signal Ground
3	LVDS_TX3_P	LVDS Data 3 (positive)
4	LVDS_TX3_N	LVDS Data 3 (negative)
5	GND	Signal Ground
6	CLK_LVDS_P	LVDS Clock (positive)
7	CLK_LVDS_N	LVDS Clock (negative)
8	GND	Signal Ground
9	LVDS_TX2_P	LVDS Data 2 (positive)
10	LVDS_TX2_N	LVDS Data 2 (negative)
11	GND	Signal Ground

Pin	Signal	Description
12	LVDS_TX1_P	LVDS Data 1 (positive)
13	LVDS_TX1_N	LVDS Data 1 (negative)
14	GND	Signal Ground
15	LVDS_TX0_P	LVDS Data 0 (positive)
16	LVDS_TX0_N	LVDS Data 0 (negative)
17	GND	Power Ground
18	GND	Power Ground
19	V3P3_LVDS_PANEL	LVDS Panel Power (+3.3V)
20	V3P3_LVDS_PANEL	LVDS Panel Power (+3.3V)

### LVDS Backlight (J8)

Table 12. LVDS Backlight Connector Pinout

Pin	Signal	Description
1	LVDS_BKLT_EN	Backlight Enable for LVDS panel
2	GND	Ground
3	LVDS_BKLT_CTRL	Backlight Control for LVDS panel (PWM)
4	V_LVDS_BKLG	Voltage for LVDS Backlight control

### Touchscreen (J21)

Table 13. Touchscreen Pinout

Pin	Signal	Description
1	CLK_I2C2_SCL	I <sup>2</sup> C Bus Clock
2	GND	Ground (black wire)
3	I2C2_SDA	I <sup>2</sup> C Bus Data
4	GND	Ground (black wire)
5	GP_IRQ#	General Purpose Interrupt Request Input (active low)
6	GND	Ground (black wire)
7	SYSTEM_RST#	System Reset output (active low)
8	V3P3_LVDS	+3.3V Power

## I/O Interfaces

### USB Interfaces (J1)

Table 14. USBx2 2.0 Connector Pinout

Pin	Signal	Description
T1	V5_USB0_OTG	Top Connector Switched USB +5V Power
T2	USB0_OTG_N	USB OTG DN diff pair -
T3	USB0_OTG_P	USB OTG DP diff pair +
T4	GND	Top Connector Ground
TM1	V5_USB1_H1	Bottom Connector Switched USB +5V Power
TM2	USB1_H1_N	USB Host1 DN diff pair -
TM3	USB1_H1_P	USB Host1 DP diff pair +
TM4	GND	Bottom Connector Ground

### User I/O (J13)

Table 15. User I/O Pinouts

Pin	Signal	Description
1	GPIO9	3.3V General Purpose I/O
3	PB_CTL_PWR#	Open-Drain Push Button Control Power Input
5	PB_CTL_RST#	Open-Drain Push Button Control Reset Input
7	PLED#	Open-Drain 3.3V max Programmable LED driver
9	LED_ETH_GRN#	Open-Drain 3.3V max Ethernet LED driver
11	WDOG1#	Watch dog 1 Output
13	GPIO1	3.3V General Purpose I/O
15	GND	Ground
17	GPIO4	3.3V General Purpose I/O
19	GPIO5	3.3V General Purpose I/O
21	GND	Ground
23	GPIO8	3.3V General Purpose I/O
25	V_BATT	Battery Input (3.0V Coin Cell)
27	GND	Ground (for V5)
29	V_MAIN	V_MAIN power. Can be supplied by this connector or provided to add-in cards through this connector. (bypassed to ground). Voltage can be 8V to 17V (default 12V).

Pin	Signal	Description
2	GND	Ground
4	GND	Ground (for PB_CTL_PWR#)
6	GND	Ground (for PB_CTL_RST#)
8	V3P3	3.3V power for Programmable LED
10	V3P3	3.3V power for Ethernet LED
12	GND	Ground
14	GPIO2	3.3V General Purpose I/O
16	GPIO3	3.3V General Purpose I/O
18	GND	Ground
20	GPIO6	3.3V General Purpose I/O
22	GPIO7	3.3V General Purpose I/O
24	GND	Ground
26	RETURN_BATT/GND	Tied to GND on CPU board and direct to the battery minus terminal on a paddleboard or external battery connector.
28	GND	Ground (for V5)
30	V_MAIN	V_MAIN power. Can be supplied by this connector or provided to add-in cards through this connector. (bypassed to ground). Voltage can be 8V to 17V (default 12V).

### CAN Interface (J17)

Table 16. CAN Pinouts

Pin	J17 Signal	Description
1	CAN1_P	CANH signal for CAN bus
2	CAN1_N	CANL signal for CAN bus
3	GND	Ground
4	V5	5V power (for off-board use)

### COM1 Interface (J16)

Table 17. COM1 Pinout

Pin	Signal	Description
1	COM1_RTS	COM1 RS-232 Request to Send
2	COM1_TXD#	COM1 RS-232 Transmit Data (active low)
3	COM1_CTS	COM1 RS-232 Clear to Send
4	COM1_RXD#	COM1 RS-232 Receive Data (active low)
5	GND	Ground

### Cellular Socket (J20A and J20B together form 20-pin socket)

The design of the cellular socket fully supports the NimbeLink Skywire modems. With minimal board customizations, the socket can also support some Digi XBee and XBee3 modems or RF Modules.

**Note:** XBee and XBee3 are available via customization. For more information, please contact VersaLogic.

Table 18. Cellular Socket Pinout

J20(A) Pin	Skywire Cellular Modems Socket Signal	XBee/XBee3 Cellular Modems (or Other RF) Socket Signal Custom Option	Skywire Description for Socket Default	XBee/XBee3 RF Modules Description for Customization Option
1	VCC	VCC	Main Power Supply for Modem (4.0V)	Main Power Supply for Modem (stuff option to change to 3.3V)
2	DOUT	DOUT (DIO13)	Cellular Modem UART data out	Same (GPIO on XBee3 RF)
3	DIN	DIN (CONFIG#/DIO14)	Cellular Modem UART data in	Same (GPIO on XBee3 RF)
4	GND	DIO12/SPI_MISO	Ground for socket on Skywire	GPIO/SPI data output line Defaults to disabled, so hard GND signal OK.

J20(A) Pin	Skywire Cellular Modems Socket Signal	XBee/XBee3 Cellular Modems (or Other RF) Socket Signal Custom Option	Skywire Description for Socket Default	XBee/XBee3 RF Modules Description for Customization Option
5	RESET#	RESET#	Modem active-low reset input, must be driven low for 20 msec minimum (on some modems) and then released to activate. Internally (on modem) pulled up to VCC or an I/O voltage rail. Must be driven with an open collector output without a pull resistor. After power-on, only use in emergency (not a "graceful" reset).	Same
6	VUSB	PWM0/RSSI/DIO10 or USB_VBUS	USB Power Detection Pin (4.5V to 5.5V). Used to turn on the USB interface. Disabled by default, but can be electronically switched on along with the differential pair on pins 7 and 8 to provide the USB interface to the Skywire.	PWM Output 0 / RX Signal Strength Indicator / Digital I/O 10, defaults to output on all Digi modems. Can be configured on LTE-M modem for the USB interface use, but suggested use is 3.3V instead of 5V. Stuff option to connect switch to 3.3V.
7	USB_D+	USB_D+ (PWM1/DIO11)	USB differential Data + signal	Same on some. (PWM Output 1 / Digital I/O 11, defaults to disabled)
8	USB_D-	USB_D- or RSVD	USB differential Data - signal	Same on some. (Reserved on XBee/XBee3, defaults to disabled)
9	WAKE or DTR#	DTR# (SLEEP_RQ/DIO8)	Wakes up the modem from low power modes. Default configuration for wakeup is a low to high transition on this line. Data Terminal Ready (active low) on some modems. Pulled-down on board by default.	Data Terminal Ready (Sleep Control Line / Digital I/O 8)
10	GND	GND	Power/Signal Ground for socket	Same
11	GND	DIO4/SPI_MOSI	Ground for socket on Skywire	GPIO/SPI data input line Defaults to disabled, so hard GND signal OK.
12	CTS#	CTS# (DIO7)	Cellular Modem UART Clear to Send hardware flow control out	Same (Digital I/O 7)
13	ON_STATUS	ON/SLEEP# (DIO9)	Modem status indicating it is on and ready for commands when high (it can be idle, blink with activity, or off in sleep mode). NC if not used.	Module status indicator (Digital I/O 9)
14	VREF	Reserved/VREF	Voltage reference for I/O signals (set to 3.3V), drives input voltage side of modem buffers converting external I/O voltage from VREF to the I/O voltage used to drive the onboard modem module for Skywire.	Not supported on XBee or XBee3 Modems, but used on other XBee devices for analog voltage reference. Could be switched off for customs.

J20(A) Pin	Skywire Cellular Modems Socket Signal	XBee/XBee3 Cellular Modems (or Other RF) Socket Signal Custom Option	Skywire Description for Socket Default	XBee/XBee3 RF Modules Description for Customization Option
15	GND	Associate/DIO5	Ground for socket on Skywire	Defaults to Associated Indicator Output (Digital I/O 5) Since this pin must be grounded per Skywire, it has a 0 Ohm resistor to GND. Customs could remove the resistor and use the pad as a test point.
16	RTS#	RTS# (DIO6)	Cellular Modem UART Request to Send hardware flow control in. Pulled-down on board by default.	Same (Digital I/O 6)
17	Reserved, I <sup>2</sup> C, or GPIO	AD3/DIO3/SPI_SS#	Most Skywire modems have this as a 1.8V GPIO, but the SVZM20 has it reserved and the QBG96 has is as an I <sup>2</sup> C data signal. NOT CONNECTED	Analog Input 3 / Digital I/O 3 / SPI low enabled select line (defaults to disabled) NOT CONNECTED
18	Reserved, I <sup>2</sup> C, or GPIO	AD2/DIO2/SPI_CLK	Most Skywire modems have this as a 1.8V GPIO, but the SVZM20 has it reserved and the QBG96 has is as an I <sup>2</sup> C clock signal. NOT CONNECTED	Analog Input 2 / Digital I/O 2 / SPI clock line (defaults to disabled) NOT CONNECTED
19	RING or ADC1	AD1/DIO1/SPI_ATTN#	RING signal wakes up a host processor when there is incoming traffic on the network. ADC1 is an analog input (0 to 1.2V). NC if not used. Default is to pull-down (1k) this pin, but have stuff option to connect it to an i.MX6 GPIO for customs.	Analog Input 1 / Digital I/O 1 / SPI Attention low enabled line output (defaults to disabled)
20	ON_OFF or PWR_ON	AD0/DIO0	ON_OFF = Modem PWR_ON is active low internally pulled up to internal I/O rail with resistor. Do not use external pull ups. Note: If you want modem to turn on automatically when power is applied, permanently tie this signal to GND using stuff option.	Analog Input 0 / Digital I/O 0 (defaults to input)

## Push Buttons

Table 19. Push Buttons and Designators

Reference Designator	Signal Name	Description
S1	PB_CTL_RST#	Push Button Control for Power-On Reset
S2	PB_CTL_PWR#	Push Button Control for PMIC Power Outputs

**Notes:**

- 1) A momentary push of S1 or a low pulse (~100ms or more) using an open-drain driver from the User I/O connector pin (J13 – pin 5) will force a reset of the board.
- 2) Holding the S2 power pushbutton in or driving the signal low (using open-drain driver) from the User I/O connector pin (J13 - pin 3) is the only way to turn off the power to the processor and I/O when the board input power is still being applied.



# Appendix A – References

---

# 5

- [Yocto Linux User Guide for the VL-EPC-2702](#)
- [i.MX6Dual/6Quad Applications Processors for Industrial Products Datasheet](#)
- [i.MX6Solo/6DualLite Applications Processors for Industrial Products Datasheet](#)
- [Hardware Development Guide for i.MX6 Families of Application Processors](#)
- NXP Website Documentation for the Quad: [https://www.nxp.com/products/processors-and-microcontrollers/arm-based-processors-and-mcus/i.mx-applications-processors/i.mx-6-processors/i.mx-6quad-processors-high-performance-3d-graphics-hd-video-arm-cortex-a9-core:i.MX6Q?tab=Documentation\\_Tab](https://www.nxp.com/products/processors-and-microcontrollers/arm-based-processors-and-mcus/i.mx-applications-processors/i.mx-6-processors/i.mx-6quad-processors-high-performance-3d-graphics-hd-video-arm-cortex-a9-core:i.MX6Q?tab=Documentation_Tab)
- NXP Website Documentation for the DualLite: [https://www.nxp.com/products/processors-and-microcontrollers/arm-based-processors-and-mcus/i.mx-applications-processors/i.mx-6-processors/i.mx-6duallite-processors-dual-core-3d-graphics-hd-video-arm-cortex-a9-core:i.MX6DL?tab=Documentation\\_Tab](https://www.nxp.com/products/processors-and-microcontrollers/arm-based-processors-and-mcus/i.mx-applications-processors/i.mx-6-processors/i.mx-6duallite-processors-dual-core-3d-graphics-hd-video-arm-cortex-a9-core:i.MX6DL?tab=Documentation_Tab)

## KNOWN ISSUES

---

**J13** cannot be used as an alternate power supply input. Do not connect anything to J13 pins 29 and 30. Rev 1.00A connects V\_MAIN to these pins so that they may be used alternatively to supply board power.

J21 pin out for 0.10A is:

Pin	Signal	Direction Relative to Our Product	Description
1	CLK_I2C2_SCL	Out	I <sup>2</sup> C Bus Clock
2	GND	--	Ground (black wire)
3	I2C2_SDA	In/Out	I <sup>2</sup> C Bus Data
4	GND	--	Ground (black wire)
5	GP_IRQ#	In	General Purpose Interrupt Request Input (active low)
6	GND	--	Ground (black wire)
7	SYSTEM_RST#	Out	System Reset output (active low)
8	GND	--	Ground (black wire)

Rev 1.00A changes pin 8 from GND to V3P3\_LVDS so that wiring to a touch panel is simplified.